

# Walkera Creaa 400

Channel 1: **Channel 1 Aile**  
 Channel 2: **Channel 2 Elev**  
 Channel 3: **Channel 3 Throttle**  
 Channel 4: **Channel 4 Rudd**  
 Channel 5: **Channel 5 Aux**  
 Channel 6: **Channel 6 Pitch**

Model Type: **Heli 90**  
 Stick Type: **Mode 1**

<b>Normal/Reverse</b>	<b>End Point</b>	<b>Throttle (Normal/Idle)</b>		<b>Pitch (Normal/Idle)</b>	
Channel 1: <b>N</b>	Channel 1: <b>120 120</b>	P1: <b>-16</b>	<b>100</b>	P1: <b>35</b>	<b>14</b>
Channel 2: <b>N</b>	Channel 2: <b>120 120</b>	P2: <b>12</b>	<b>75</b>	P2: <b>50</b>	<b>33</b>
Channel 3: <b>R</b>	Channel 3: <b>60 110</b>	P3: <b>40</b>	<b>70</b>	P3: <b>62</b>	<b>50</b>
Channel 4: <b>N</b>	Channel 4: <b>55 55</b>	P4: <b>60</b>	<b>75</b>	P4: <b>73</b>	<b>66</b>
Channel 5: <b>N</b>	Channel 5: <b>100 100</b>	P5: <b>100</b>	<b>100</b>	P5: <b>82</b>	<b>79</b>
Channel 6: <b>R</b>	Channel 6: <b>120 120</b>				

<b>Swash AFR</b>	<b>Dual Rate (On/Off)</b>		<b>SubTrim</b>	
Channel 1: <b>100</b>	Channel 1: <b>100</b>	<b>100</b>	Channel 1: <b>0</b>	Channel 4: <b>0</b>
Channel 2: <b>100</b>	Channel 2: <b>100</b>	<b>100</b>	Channel 2: <b>0</b>	Channel 5: <b>0</b>
Channel 6: <b>100</b>	Channel 4: <b>100</b>	<b>100</b>	Channel 3: <b>0</b>	Channel 6: <b>0</b>

<b>Switch</b>	<b>Variable</b>
Switch a: <b>Normal/Idle</b>	Variable a: <b>Pitch Adjust</b>
Switch b: <b>Throttle Cut</b>	Variable b: <b>Null</b>

<b>Mix 1</b>		<b>Mix 2</b>		<b>Mix 3</b>	
Source	<b>Variable B</b>	Source	<b>Variable B</b>	Source	<b>Channel 3</b>
Destination	<b>Channel 5</b>	Destination	<b>Channel 6</b>	Destination	<b>Channel 1</b>
Up Rate	<b>100</b>	Up Rate	<b>100</b>	Up Rate	<b>36</b>
Down Rate	<b>100</b>	Down Rate	<b>100</b>	Down Rate	<b>32</b>
Switch	<b>On</b>	Switch	<b>Off</b>	Switch	<b>Off</b>

## Notes

Creaa 400, 3S 2200mAh 11,1V , WK-WS26-001  
 Engine CUT Switch B  
 Wash AFR All 100%